




FUTURETRONICS

Features & Instructions

FUT-7188 POWER DOCK

For use with Nintendo™ Wii™

- 1) Turn off the mains power and remove plug from the power point.
- 2) Unplug the power supply plug from the Wii™ console




- 3) Plug the piggy back adaptor plug into the Wii™ console, where the power supply plug normally goes



- 4) Plug the original Wii™ power supply plug on to the other side of the piggy back adaptor plug



- 5) Plug the circular ended plug into the back of the Power Dock



- 6) Plug mains power plug back into the power point then turn main power back on
- 7) Replace existing batteries with the rechargeable batteries which are included
- 8) Place remote with the rechargeable battery on the Power Dock at any time to charge



- 9) The switch on the the back of the Power Dock turns the blue illumination at the base of the Power Dock on and off

Note:

- We recommend charging the batteries over night on the 1st charge to prolong the life of the battery

- Batteries must be installed into the remote in order for it to charge

Nintendo™ Wii™ is a trademark or registered trademarks of Nintendo™.
This product is not designed, manufactured, sponsored or endorsed by Nintendo™.

www.futuretronics.com.au

